

LED OUTDOOR BOLLARD LIGHT

INSTALLATION GUIDE

Eurolumen

MODEL ELA900

ROUND 360-DEGREE BOLLARD / SURFACE FLANGE

1



VERIFY FIXTURE / 800 mm / 3-ANCHOR FLANGE

2



POSITION FLANGE / MARK 3 ANCHORS + CABLE ENTRY

3



DRILL / SET 3 ANCHORS / PREPARE SEALED CONDUIT

4



ISOLATE SUPPLY / CONNECT L-N-PE / SEAL JOINT

5



LOWER UPRIGHT / LEVEL / TIGHTEN 3 FASTENERS

6



POWER ON / COMMISSION / VERIFY 360-DEGREE OUTPUT

BOLLARD POWER + FOUNDATION SEQUENCE

220 V SUPPLY

ISOLATOR + EARTH

SEALED CONDUIT

CENTRAL ENTRY

IP-RATED JOINT

L / N / PE

ELA900

EXTERNAL 3-POINT FLANGE

1. Provide a level concrete footing sized for the site load; keep the conduit at the base centre.

2. Use all three model-specific fixing points and corrosion-resistant foundation anchors.

3. Keep the field joint dry and sealed; do not bury an unapproved connector directly in soil.

4. Confirm product orientation and plumb before tightening the anchors evenly and commissioning.

DO NOT ENERGIZE UNTIL THE BASE, EARTH, GLAND AND ALL ANCHORS ARE SECURE.

ELA900 INSTALLATION DATA

HEIGHT OPTIONS	400 / 600 / 800 mm
ILLUSTRATED HEIGHT	800 mm
HEAD / BODY	HEAD D160 / POLE D76
BASE	D109 x T6 mm
ANCHOR PATTERN	3 x 14 x 20 mm SLOTS
POWER / INPUT	10 W / 20 W / 220 V
OUTPUT	360 DEG. / ON-OFF



Installation must be performed by qualified personnel using the supplied or specified mounting parts.

Confirm model, height, voltage, base geometry, anchor positions and underground services before drilling.

The concrete footing, cable gland and electrical joint must be suitable for the site and outdoor exposure.

Retain this guide with the project handover and maintenance records.



WARNING

- ISOLATE POWER BEFORE INSTALLATION, CLEANING OR SERVICE.

- VERIFY BURIED SERVICES, ANCHORS, EARTH, SEALS AND PLUMB BEFORE POWER ON.

CE

PE OUTDOOR