

LED OUTDOOR BOLLARD LIGHT INSTALLATION GUIDE

Eurolumen

MODEL ELA911

CURVED DISC-HEAD BOLLARD

1



VERIFY FIXTURE / 400 mm / 4-ANCHOR BASE

2



POSITION ACTUAL BASE / MARK 4 ANCHORS + ENTRY

3



DRILL / SET 4 ANCHORS / PREPARE SEALED CONDUIT

4



ISOLATE SUPPLY / CONNECT L-N-PE / SEAL JOINT

5



LOWER UPRIGHT / LEVEL / TIGHTEN 4 FASTENERS

6



POWER ON / COMMISSION / VERIFY 360-DEGREE OUTPUT

BOLLARD POWER + FOUNDATION SEQUENCE

220 V SUPPLY
ISOLATOR + EARTH

SEALED CONDUIT
CENTRAL ENTRY

IP-RATED JOINT
L / N / PE

ELA911
ROUND 4-POINT FLANGE

1. Provide a level concrete footing sized for the site load; keep the conduit at the base centre.

2. Use all four model-specific fixing points and corrosion-resistant foundation anchors.

3. Keep the field joint dry and sealed; do not bury an unapproved connector directly in soil.

4. Confirm product orientation and plumb before tightening the anchors evenly and commissioning.

DO NOT ENERGIZE UNTIL THE BASE, EARTH, GLAND AND ALL ANCHORS ARE SECURE.

ELA911 INSTALLATION DATA

HEIGHT OPTIONS	400 / 600 / 800 mm
ILLUSTRATED HEIGHT	400 mm
HEAD / BODY	TILTED HEAD D180
BASE	D90 x T6 mm
ANCHOR PATTERN	4 ANCHOR HOLES
POWER / INPUT	8 W / 220 V
OUTPUT	360 DEG. / ON-OFF



Installation must be performed by qualified personnel using the supplied or specified mounting parts.

Confirm model, height, voltage, base geometry, anchor positions and underground services before drilling.

The concrete footing, cable gland and electrical joint must be suitable for the site and outdoor exposure.

Retain this guide with the project handover and maintenance records.



WARNING

- ISOLATE POWER BEFORE INSTALLATION, CLEANING OR SERVICE.

- VERIFY BURIED SERVICES, ANCHORS, EARTH, SEALS AND PLUMB BEFORE POWER ON.

CE

PE OUTDOOR