

LED OUTDOOR WALL LIGHT
INSTALLATION GUIDE

Eurolumen

MODEL ELA301

UP/DOWN CYLINDER WALL LIGHT

1

VERIFY FIXTURE / WALL PLATE / HARDWARE

2

RELEASE HOUSING / REMOVE MOUNTING BASE

3

LEVEL BASE / MARK + DRILL ANCHORS

4

FIX BASE / CONNECT L-N-PE / SEAL CABLE

5

SEAT LUMINAIRE / LOCK REAR HOUSING

6

POWER ON / COMMISSION / VERIFY UP-DOWN BEAMS

OUTDOOR WALL POWER CONNECTION

MATCHED SUPPLY
24 V DC / 220 V AC

PROTECTED CIRCUIT
ISOLATOR + EARTH

IP-RATED JOINT
SEALED WALL ENTRY

ELA301
SYMMETRICAL UP / DOWN

1. Isolate and verify the supply before removing the wall plate or wiring.

2. Keep the model-specific mounting base level and use every supplied fixing point.

3. Seal the cable entry and rear gasket before seating the luminaire housing.

4. Confirm the housing lock is secure before final commissioning.

DO NOT ENERGIZE UNTIL THE WALL BASE, EARTH, GLAND AND HOUSING LOCK ARE SECURE.

WALL LIGHT INSTALLATION DATA

PRODUCT SIZE	BODY D65 x H162 / REAR BOX H100 x P50
POWER	10 W
INPUT OPTIONS	24 V DC / 220 V AC
MOUNTING	RECTANGULAR 4-ANCHOR PLATE / SIDE LOCK
OUTPUT	SYMMETRICAL UP / DOWN
LOCATION	OUTDOOR WALL
FINAL CHECK	LEVEL / LOCK / SEAL / TEST

Installation must be performed by qualified personnel using the supplied mounting parts.

Confirm the model, voltage, exact mounting base, anchor positions and cable route before drilling.

The rear gasket and cable seal must remain continuous against the finished wall.

Retain this guide with the project handover and maintenance records.

WARNING

- ISOLATE POWER BEFORE INSTALLATION, CLEANING OR SERVICE.

- VERIFY ANCHORS, EARTH, WALL SEAL AND HOUSING LOCK BEFORE POWER ON.

CE

PE OUTDOOR