


LED RING PENDANT LIGHT
INSTALLATION GUIDE

Eurolumen

MODEL ELX525

PENDANT / CEILING CANOPY / MECHANICAL SUPPORT

1



CHECK PRODUCT AND MOUNTING COMPONENTS

2



SWITCH OFF AND ISOLATE MAINS POWER

3



FIX CANOPY PLATE / ATTACH STEM

4



CONNECT TERMINAL / SUPPORT RING

5



SECURE CANOPY / CHECK STEM & LEVEL

6



CHECK LEVEL / POWER ON

WIRING DIAGRAM

POWER SUPPLY
220V AC

CEILING TERMINAL
L / N / PE

CANOPY / DRIVER
CONFIRM LABEL

LED LUMINAIRE
TEST OUTPUT

1. Isolate the mains supply before opening or installing the luminaire.

2. Connect L, N and protective earth only as marked on the supplied terminal.

3. Keep conductors and the terminal block fully enclosed by the body or canopy.

4. Confirm the selected control interface matches the ordered configuration.

FOLLOW THE PRODUCT LABEL AND LOCAL ELECTRICAL INSTALLATION RULES.

INSTALLATION DATA

MODEL	ELX525
INSTALLATION	RING PENDANT
MOUNTING	CANOPY / RIGID CENTER STEM
PRODUCT SIZE	DIA. 300 / 400 / 500 mm
INPUT	220V AC
POWER OPTIONS	20 / 25 / 30 W
CCT / CRI	2700-4000K / CRI 90
BEAM OPTIONS	110 DEG.
CONTROL	DALI / BLUETOOTH / 0-10V / ON-OFF
LOCATION	INDOOR / DRY LOCATION / IP20



Installation of this product must be performed under the guidance of qualified technical personnel.

Switch off and isolate the mains supply before installation, adjustment or maintenance.

If the product has been updated, contact Eurolumen to confirm the latest installation instructions.

Eurolumen reserves the right of final interpretation. Retain this guide with the project records.



WARNING

- INSTALL ONLY WITH MAINS POWER OFF AND BY QUALIFIED PERSONNEL.

- VERIFY CEILING FIXINGS, TERMINALS AND MECHANICAL SUPPORTS BEFORE POWER ON.

CE

RoHS

IP20

INDOOR