

LED OUTDOOR WALL LIGHT INSTALLATION GUIDE

Eurolumen

MODEL ELA309

4-LENS SQUARE WALL LIGHT



VERIFY FIXTURE / SMALL FIXING PLATE / HARDWARE



LEVEL SMALL FIXING PLATE / MARK ANCHORS



DRILL / ANCHOR / FIX SMALL PLATE TO WALL



CONNECT L-N-PE / SEAL CABLE ENTRY




SLIDE HOUSING OVER PLATE / LOCK SIDE SCREW



POWER ON / COMMISSION / VERIFY UPWARD OUTPUT

OUTDOOR WALL POWER CONNECTION



1. Isolate and verify the supply before positioning the small internal fixing plate.
2. Level and fasten the small fixing plate first; route the cable through its centre opening.
3. Complete and seal the connection before sliding the luminaire housing over the plate.
4. Tighten the side retaining screw before final commissioning.

DO NOT ENERGIZE UNTIL THE WALL BASE, EARTH, GLAND AND HOUSING LOCK ARE SECURE.

WALL LIGHT INSTALLATION DATA

PRODUCT SIZE	SQUARE BODY 80 x 80 x H123 / BASE L103
POWER	8 W
INPUT OPTIONS	24 V DC / 220 V AC
MOUNTING	SMALL INTERNAL FIXING PLATE / REAR MATE / SIDE LOCK
OUTPUT	UPWARD WALL WASH
LOCATION	OUTDOOR WALL
FINAL CHECK	LEVEL / LOCK / SEAL / TEST



Installation must be performed by qualified personnel using the supplied mounting parts.
Confirm the model, voltage, exact mounting base, anchor positions and cable route before drilling.
The rear gasket and cable seal must remain continuous against the finished wall.
Retain this guide with the project handover and maintenance records.



WARNING

- ISOLATE POWER BEFORE INSTALLATION, CLEANING OR SERVICE.
- VERIFY ANCHORS, EARTH, WALL SEAL AND HOUSING LOCK BEFORE POWER ON.

CE PE OUTDOOR